


FORD TRANSIT CONNECT LWB WALL LINER INSTALLATION INSTRUCTIONS




NOTES:


1. Before commencing, remove all wall liners and “D” Rings already installed in the vehicle.
2. Consult layout PDF and compare vehicle layout allocated Legend.
3. Prepare hardware shown below and have them ready for installation.
4. Wall liners will be installed in the order shown in the instructions.
5. A drill with a Phillips driver is required to install (C) #8 Screws) shown below.
6. Reinstall all “D” Rings once the wall liner kit installation is completed.



TRANSIT CONNECT LWB WALL LINERS



PARTIAL REAR PANEL KIT





FULL REAR PANEL KIT

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	723-114-2613	GREY BOTTOM PANEL SLIDING DOOR TRANSIT CONNECT LWB	2
2	723-114-2613	GREY UPPER DOOR PANEL PASSENGER SIDE SLIDING DOOR	1
3	723-114-2613	GREY UPPER DOOR PANEL DRIVER SIDE SLIDING DOOR	1
4	RETAINER	RETAINER- BLACK NYLON	33
5	SCREW	SCREW - PHIL. PAN HD #8X.75 SELF DRILLING	59
6	SCREW CAP	SCREW CAP	36
7	723-114-2613	GREY REAR DOOR UPPER PANEL TRANSIT CONNECT LWB	1
8	723-114-2613	GREY REAR UPPER DOOR PANEL DRIVER SIDE TRANSIT CONNECT LWB	1
9	725-114-2613	GREY CEILING PANEL TRANSIT CONNECT LWB	1
10	727-151-1010	REAR CEILING SILL DRIVER SIDE TRANSIT CONNECT LWB	1
11	727-151-1010	FRONT CEILING SILL DRIVER SIDE TRANSIT CONNECT LWB	1
12	727-151-1010	REAR CEILING SILL PASSENGER SIDE TRANSIT CONNECT LWB	1
13	727-151-1010	FRONT CEILING SILL PASSENGER SIDE TRANSIT CONNECT LWB	1
14	724-114-2613	GREY REAR UPPER PANEL DRIVER SIDE TRANSIT CONNECT LWB	1
15	724-114-2613	GREY REAR UPPER PANEL PASSENGER SIDE TRANSIT CONNECT LWB	1
16	722-XXX-6541	TRANSIT CONNECT FLOOR	1
17	728-151-1010	FLOOR SILL REAR DOOR TRANSIT CONNECT	1
18	726-151-1010	FLOOR SILL SIDE DOOR TRANSIT CONNECT	2

Hardware quantity will vary depending on the kit required; refer to Layout drawings for appropriate quantity.

Driver Side Wall Liner Installation



1: Install Item 1, 2, Front Driver Side Panels.

Note; Depending on the model of vehicle you have purchased, the panels may be full or partial.

For Dual sliding doors vehicles you will require the partial Upper and Bottom panels.

First remove OEM bottom panel.

Sliding door must be closed to install panel;


- Align notch and edge of panel with the feature on the vehicle driver side front then align opposite side of panel edge with the contour features.
- Install hardware (A) on the Bottom panel, hardware (B,C) on the Upper panel, in the holes provided, on the bottom of the panel first, working your way up the panel to the top.

2: Install Item 14, Rear Driver Side Panel.

Note; Depending on the model of vehicle you have purchased, the panels may be full or partial.


- Align wheel well edge of the panel with the feature on the vehicle; position the contour of the panel to the vehicle wall.
- Install hardware (A), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.

Installation completed




Back Door Wall Liner Installation

ITEM 7
UPPER DOOR
PASSENGER SIDE
PANEL



ITEM 8
UPPER DOOR
DRIVERS SIDE
PANEL




B, C

3: Install Item 7 and 8, Upper door panels,



- Align the Upper panels with the upper door contours as well as with the door lock opening.
- Install hardware (B, C), in the holes provided, on the top of the panel first, working your way down the panel to the bottom.

Note; make sure doors are closed for the installation


Installation completed



Passenger Side Wall Liner Installation



Installation completed



4: Install Item 15, Rear Passenger Side Bottom Panel.

Note: Depending on the model of vehicle you have purchased, the panels may be full or partial.



- Align wheel well edge of the panel with the feature on the vehicle; position the contour of the panel to the vehicle wall.
- Install hardware (A), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.

5: Install Item 1, Bottom Sliding Door Panel. First remove OEM bottom panel.

Note: Sliding door must be closed to install panel;

- Insert panel into the sliding door sill cavity, align holes at the bottom half of the panel to the one on the door and insert hardware (A) in all of the holes.
- Install Item 2, Sliding Door Top Panel with hardware (B, C) in the holes provided.

Ceiling Liner Installation




6: Install Item 9, Ceiling Panel.

- Before starting bend the scribed edges on the panel shown above to help in the installation.
- Align Ceiling panel with the feature on the vehicle in the front, insert the front of the panel between the headliner and the roof.
- Align the outside holes at the center of the panel with the holes in the ceiling cross bows and install hardware (A) on each side; this will align the panel with the ceiling.
- Push the panel against the ceiling and install hardware (A), in the holes provided.

Ceiling Liner Installation

Installation completed

VEHICLE IS UPSIDE DOWN



Ceiling Sills Installation

FRONT



VEHICLE IS UPSIDE DOWN

ITEM 13
FRONT CEILING
SILL PASSENGER
SIDE

PASSENGER SIDE

WALL


ITEM 12
REAR CEILING
SILL
PASSENGER
SIDE





7: Install Item 12 and item 13 with hardware (C) in the holes provided.

- First, position Item 12 in the rear corner by pushing upwards on the ceiling and then on the wall and fasten with hardware (C) first on the wall, afterwards install hardware (C) on the ceiling portion of the panels.
- Second, position Item 13 in the front corner by pushing upwards on the sill and then on the ceiling and fasten with hardware (C) first on the wall side of the sill, afterwards install hardware (C) on the ceiling side of the sill.
- Items 10 and 11 are installed the same way on the driver's side of the vehicle

Ceiling Sills Installation Details




Floor and Floor Sill Installation



8: Install Items 16, FLOOR and Items 17, 18 FLOOR SILLS.

- Install floor inside the vehicle.
- Align the floor sills in their proper location with the floor edges as shown and install hardware (C) as shown. Holes are provided in the floor for the D-Rings to be re-installed.

Installation completed



Location of Spacer Foam Ford Transit Cargo Vans

Towards front of the vehicle
→

